




WiZ



Caution:
When the product is used outdoors
the mains plug must be connected to
socket outlet located indoors

WiZ Fairy Light Manual
9290041012, 9290041013
9290041016

Incl.






160 LEDs


9290041012 9290041013 9290041016





B



1




!




2



3



4



5

